

# UniMate Quick Start Guides

From SecuTech Wiki

Version 1.0

Version	Date
1.0	2017.9

The data and information contained in this document cannot be altered without the express written permission of SecuTech Solution Inc. No part of this document can be reproduced or transmitted for any purpose whatsoever, either by electronic or mechanical means.

The general terms of trade of SecuTech Solution Inc. apply. Diverging agreements must be made in writing.

Copyright SecuTech Solution Inc. All rights reserved.

Contact Information

Web: <http://www.esecutech.com>

Email: [sales@esecutech.com](mailto:sales@esecutech.com) (<mailto:sales@eSecuTech.com>)

Please Email any comments, suggestions or questions regarding this document or our products to us at: [sales@esecutech.com](mailto:sales@esecutech.com) (<mailto:sales@eSecuTech.com>).

## UniMate USB/USB Mini/Drive



### UniMate USB/USB Mini Features

- \* CCID
- \* FIPS Certificated
- \* Smart Card
- \* PKCS#11 Supported
- \* MS-CAPI Supported
- \* X.509 Certificate Supported
- \* Two-Factor Authentication
- \* Globally Unique Hardware ID
- \* Multi-Level Permission Management
- \* Secure File System
- \* Virtual CD-ROM



- \* Customisable Device Name
- \* Onboard Hashing: MD5, SHA-1, SHA-224, SHA-256, SHA-384, SHA-512
- \* Onboard Encryption Algorithms: 128- 192- and 256-bit AES (ECB, CBC), DES (ECB, CBC), 3DES (ECB, CBC), GOST28147, 1024- and 2048-bit RSA, DSTU4145-series

## UniMate Drive Features



- \* PKCS#11 Supported
- \* MS-CAPI Supported
- \* X.509 Certificate Supported
- \* Two-Factor Authentication
- \* Globally Unique Hardware ID
- \* Multi-Level Permission Management
- \* Secure File System
- \* Normal Drive
- \* Virtual CD-ROM
- \* Highly Configurable
- \* Customisable Device Name
- \* Onboard Hashing: MD5, SHA-1, SHA-224, SHA-256, SHA-384, SHA-512
- \* Onboard Encryption Algorithms: 128- 192- and 256-bit AES (ECB, CBC), DES (ECB, CBC), 3DES (ECB, CBC), 1024- and 2048-bit RSA

Retrieved from "[https://esecutech.com/wiki/index.php?title=UniMate\\_Quick\\_Start\\_Guides&oldid=3794](https://esecutech.com/wiki/index.php?title=UniMate_Quick_Start_Guides&oldid=3794)"

Category: UniMate Manuals

- 
- This page was last modified on 10 August 2018, at 02:02.